

EBEEMEE TOWNSHIP

T4 R9 NWP

EBEEMEE LAKE

16-1

16-2

16-3

16-4

16-5

16-6

16-7

16-8

16-10

16-8

16-12

16-13

16-14

16

P/O 10-16

BANGOR & BROOKTON RAILROAD

P/O 6-14

SEE MAP 11

SEE MAP 9


LAKE VIEW PLANTATION

PROPERTY MAPS










Tax Map
12

BROWNVILLE
Piscataquis County, ME



DRAFT MAP - FOR REVIEW ONLY!



LEGEND

-  PROPERTY LINE
-  EASEMENT/RIGHT-OF-WAY
-  PUBLIC RIGHT-OF-WAY
-  PRIVATE RIGHT-OF-WAY
-  RAILROAD RIGHT-OF-WAY
-  HISTORIC/SUBDIVISION LINE
-  PARCEL HOOK
-  PARCEL ID NUMBER
-  SURVEY DIMENSION (FEET)

The information on this map is for assessment purposes only, is not a legal survey, and is not intended to be used for conveyance.



Original map created by J. W. Sewall Company.
Map updated by LatLong Logic, LLC.
(May 2019)

Brownville Assessor's Office
586 Main Road
Brownville, Maine 04414
(207) 965-2561